



www.farbe-aus-schweden.de
Tel.: +49 (0)40 54 80 12 20

Trägergrund V

Adhesion-primer for water-based paint

Also for oil-paint, but with a longer drying time

Characteristics:

Trägergrund V is a water-based adhesion-primer for planed wooden surfaces outdoors, where your ambition is having a topcoat with a water-based or acrylic-paint. Only like that your paint adheres optimally on planed timber. In addition, Trägergrund V is effective against cracks or discharge of resin. Application: wooden facades, doors, windows etc.



Good to know: If your wood (pine, spruce, fir) is untreated and planed always start with the oil-primer „Grundolja“ followed by the adhesion-primer „Trägergrund V“. Only like that your paint adheres optimally and the wood is simultaneously protected. Your advantages: This will prevent, for example, cracks, blisters and premature flaking of the paint. The color lasts much longer, so you save time, money and labor.

Exceptions: For roughly sawn wood, you only need the oil-primer „Grundolja“ – but not the adhesion-primer „Trägergrund V“.

Application / My ambition is...

...a coat of paint on untreated wood:

1. Do not apply as primer for wood tar, distemper-paint like “Falu Rödfärg”, thin-layered stain or interior paint. How to undercoat in this cases, please have a look at the particular data sheets.
2. *The surface has to be clean, dry and intact!* Otherwise brush or scrape off any loose material such as dirt or dust, then rinse everything with clean water and allow to dry the ground.
3. Then treat the wood with the oil-primer „Grundolja“ and let it dry for 1-2 days, depending on weather conditions.
4. Not later than 7 days, apply the adhesion-primer „Trägergrund V“. Stir well and coat one thin layer (only dip the tip of the brush into the tin and apply). Please do not dilute “Trägergrund V”! Let it dry for 1-2 days, depending on weather conditions.
5. Then apply one or two coats of your paint.

...a coat of paint on painted surfaces with exfoliated points:

1. Do not apply as primer for wood tar, distemper-paint like “Falu Rödfärg”, thin-layered stain or interior paint. How to undercoat in this cases, please have a look at the particular data sheets.
2. Grind off the exfoliated points. After that, rinse the *whole* surface with clean water and allow to dry the ground. In case of fungal decay use our moss- and mould-remover “Alg/Mögeltvätt”. *The surface has to be clean, dry and intact!*
3. On the *polished points* treat the wood with the oil-primer „Grundolja“ and let it dry for 1-2 days, depending on weather conditions.
4. Not later than 7 days, apply the adhesion-primer „Trägergrund V“ on the *polished and oiled points*. Stir well and coat one thin layer (only dip the tip of the brush into the tin and apply). Please do not dilute “Trägergrund V”! Let it dry for 1-2 days, depending on weather conditions.
5. Then apply one or two coats of your paint.

Tips:

- Do not apply as primer for wood tar, distemper-paint like “Falu Rödfärg”, thin-layered stain or interior paint. How to undercoat in this cases, please have a look at the particular data sheets.
- Avoid painting during warm or sunlit surfaces.
- Please do not dilute “Trägergrund”!
- Do not paint during rain, snow, high humidity or temperatures under +8°C – please consider the temperatures at night.
- Stir well and coat one thin layer - only dip the tip of the brush into the tin and apply in 1-3 brush marks. Otherwise “Trägergrund V” dries during brushing.

Technical Data:

Tool:	Brush	Repaintable:	After 1-2 days, depending on weather conditions
Consumption :	4-6 m ² /l on sawn wood, 6-8 m ² /l on planed wood	Cleaning:	Water and dish liquid
Coating conditions:	Minimum +8°C (also at night)	Storage time:	2 years if unopened, store frost-free